

PPG WAVEGENERATOR

The Next Generation

Version 1.0.2 - 19.10.2012



Content

1	Introduction
1	Key Features
1	Description
2	Keyboard
4	Audio Recorder
5	Wave page
5	The wave grid
8	Spectrum editor
9	Wave editor
10	Parameter Page
10	The parameter panel
11	Oscillators
13	Envelopes
14	Filter
15	Dual Amplifier
16	LFO
17	Arpeggiator
18	Delay
19	3D page
19	Image Transformer
19	Setup page
20	Setup
22	CC display
26	Browser page
28	Browser

Introduction

Key Features

- Creation of your own waves and wavetables.
- Playful sound creation simply by drawing or picking harmonics
- 3D page, visualization of the wavetables, transformation from photos into wavetables.
- 256 waves assembled within a wave grid
- 3 Audio Oscillators
- 3 Noise generators, for audio and modulations
- Classic 24 dB Lowpass Filter, combined with an overdrive simulation.
- Dual amplifier, for versatile control of 2 audio signals as well as panning.
- 13 Envelopes, for independent control of pitch, waveform, filter and noise gain and panning
- 4 LFOs
- Arpeggiator
- Delay/Reverb effect
- Audio engine with 2 synthesis modes, and variable wave blending quality.
- Directly accessible context help inside the app
- Use a camera, to shoot a picture and then transform it into a sound!
- Using state of the art technologies, but still the versatile and efficient synthesis system.

Description

PPG WaveGenerator is the latest development from the inventor of wavetable synthesis, Wolfgang Palm. It is a next generation synthesizer, building on the heritage of the PPG Wave keyboards.

The PPG WaveGenerator comes with a multitude of wavetables. The sound material contains the typical sounds from the original PPG wave models, as well as many new sounds generated by versatile analysis tools and also hand edited waves.

This app enables the user, to create his own wavetables in a playful way, and to hear the result immediately. Also you can construct the waves by adding harmonics very precise. Another way is to transform a picture into a wavetable. You can load photos from your album or even shoot a picture with the camera.

The waves are collected in a grid of 256 fields, to which the 3 oscillators of the synthesizer have arbitrary and independent access. In a 3D display you get a visual impression on how the sound evolves. You can turn around the 3D object and zoom in and out, The Parameters of the synthesizer are divided into modules, which allows easy, yet powerful editing. It contains 3 oscillators with independent control of pitch and waveform. Each oscillator has its own glide, which gives a very dynamic sound.

With a sophisticated routing system, the diverse modulation sources can be connected to all important control points. The keyboard is configurable totally freely, so you can setup all well-known musical scales, but also all imaginable custom scales that best fit into your music. PPG WaveGenerator benefits all advantages of the iPad, like X/Y control after the key on event, or two finder gestures for spectrum control. After a key is hit, the tone may be modified and modulated in various ways, just by moving your finger.

A browser lets you sort the sound programs; you can categorize and rate them. Also complete custom sound banks may be created. All significant parameters are controllable via MIDI. There is a built in context specific help for all pages and modules.

Keyboard

The keyboard can be configured in various ways. Basically there are two styles: the single row and the double row style. Additionally you may setup your own scales, like Pentatonic or Lydian or totally free.

To make your own scales, you start with the full 12 key scale and then delete the notes you don't need. Use **Reset** to get all 12 notes. Then select **Edit** from the **mode** menu, and delete the keys you want by tapping on them. When finished, switch back to one of the play modes.

To shift the keyboard up or down in octaves, select the **Shift** mode, and shift the keyboard to the left or right. You see how the note octave values change. Then switch back to your play mode.

Using **Copy** and **Paste** you can easily change the keyboard of other programs.

The X and Y controls

The iPad offers many nice features, which you won't find on hardware synths, such as polyphonic control after the key-on event! In WaveGenerator the **CX** and **CY** controllers allow you to configure various types of modulation. After touching the key, the CX value rises or falls as you move your finger to the right or left. Similarly, the CY value rises or falls as you move your finger vertically. Several CX and CY routings can be found in the controls of various routing lists on the Para page. These include controls for: Pitch, wave, filter or gain.

Please note that the CX value does not work if you are in **Legato** mode.

The CV control

CV stands for velocity control. This is normally sent from a MIDI keyboard, and depends on how hard you hit the key. In WaveGenerator this works also, but if you are using just the iPad touch-keys, we have built in a feature that lets you play the keys with velo too. It depends on the vertical position on the key-pads where you touch the key, which controls the velo. If you tap in the low part, you get soft velo, if you tap in the upper part, hard velo.

Audio Recorder

In order to export audio, WaveGenerator has a built in audio recorder. Enter **Rec** mode, and play some notes or start the Arptor.

When you tap on the **Rec** button again the recording stops, and you may select **Play** mode. The mini display shows the recorded material.

Exporting the audio.

There are two ways to export audio. One is via the iOS Pasteboard, the other is via file sharing and iTunes. In the context menu, you find the **Copy** function, which moves the audio into the iPad's Clipboard, and you can Paste it into another app. You may record up to 10 minutes stereo audio at 44.1 kHz. Please note that copying a long recording to the clipboard may take a short while.

To use file sharing, you first have to save your recording to a temporary file, using the **Save** command. Then open iTunes on your computer.

Under Devices, click on the iPad,

Go to the Apps tab

Scroll down until you see File Sharing.

Select WaveGenerator from the list and you see temprec.wav

You can Save the file to your computer from here.

Wave Page

The wave grid

The wave grid contains 16 rows with 16 places each, which can be filled up with waveforms. These waves are the basic sound-material for your programs. The way you access these waves, depends on the envelope settings and a path which connects single waves out of the grid.

Above the grid is the title bar, which shows the name of the current wavetable, the *Load* button, the load mode and the context menu with the tools. More on that later.

When you change the program, a new wavetable is loaded from the bottom of the grid upward. When you manually load a wavetable via the load icon, you have 3 options available in the popover box just to the right of the load icon:

Exchange - The old wavetable is erased and the new one is loaded.

Append - The new wavetable is loaded directly after the current content of the grid.

Over - The new wavetable is overloaded, starting at the current selection point.

The Load file list, is grouped in 3 areas:

PPG - Here you find all the wavetables which belong to the factory presets. The grey text shows the method which was used to create the wavetable.

SndD - These are wavetables which our sound-designers have created.

User - Here your own wavetables will show up.

Touching the small category label on the right, will bring you directly to that part of the list.

The wave grid operates in 7 modes:

Browse - In this mode, you may check out single waves, listen to them and get a feeling for the waveforms. You also may change the spectrum or the wave-shape directly, by using the controllers on the left side.

Note that this mode is quite slow due to the graphic power required. If you want to create new waves it might be better to do so in **Record** or **Modify** mode.

Path - Here you can define the path on which the envelopes will control the wave-access.

Linear - This is an easy way to create linear paths, which run through all points of one column. If you touch a point in the grid, the whole column will be selected. If you move from left to right, more columns will be added to the path.

Edit - Tap and drag a column of waves to another position. This is especially usable when the columns are wavetables itself, or contain material of a certain kind.

Record - In this mode, you can quickly create your own wavetables. Just drag inside the wave editor or in the spectrum view, and watch the new waves getting stored into the grid. when finished recording, switch to *Linear*, and you can play through your new waves. Note, that the record starts from the active point inside the grid.

Overdub - Here you can make changes (overdubs) to an existing wavetable. Each time you pick a point in the wave or spectrum, one wave from the wavetable is modified. The same works in **Draw** or **Over** modes of the wave and spectrum controllers. Note, that the overdub starts from the active point inside the grid.

Modify - Select a single wave from the path, and change its waveform or spectrum. You still play the complete path.

When you do changes to the waves or add more waves to the set, there appears a * behind the wavetable name. When you save the program, you will be asked to enter a new filename for the wavetable.

The wave grid tools

The context menu contains tools, which help you change the content of your wavetable.

Save - Saves the current wavetable under the name which you might have edited inside the name editor. (Note: you cannot change the factory wavetables!)

Save Path - This saves the new wavetable, but only the points which are contained in the current path. This is very helpful, when you want to compact a wave selection.

Clear - Erases all the waves from the grid.

Reset Path - Resets the path, so you can start a new one. You have to select the **Path** mode to do that (see above).

Delete Last - Deletes the last point in the path.

Normalize - corrects the gains of all waves in the grid. This is useful if you have adjusted the gains in the spectrum or wave editor too high.

Spectrum editor

The spectrum editor lets you change the waveform inside the wavegrid. This is in conjunction with the mode you have selected for the wavegrid. If you have selected **Modify** or **Browse**, you may change the wave which you last touched. You can zoom in and out to the resolution you prefer and scroll to any position inside the spectrum.

The controller has three modes:

Pick

You pick a single bar from the spectrum and change its amplitude. In this mode, you always stay on the selected bar.

Draw

In this mode, you can also change the gain, but when you move horizontally, the controller switches to another bar.

Over

You overwrite bars on the selected wave. This can be recorded into a new wavetable, using **Record** mode in the wavegrid.

Please take care, that your waves don't get too high in amplitude. This can happen if you start with a sine, and add more and more harmonics. The resulting waveform should not exceed the frame of the wave editor! If this happens, you may correct the complete wavetable with the **Normalize** tool in the grid context menu.

Spectrum Balancer

If you tab the controller with two fingers, you may change the overall spectrum tilt and gain.

Wave editor

The Wave editor lets you change the waveform directly. It works similar to the spectrum editor, but has no zoom.

The display always shows a half wave. The other half is mirrored. If you set the wavegrid into *Browse* mode, you may see the full cycle waveform, while you edit it.

The controller has three modes:

Pick

You pick a single bar (sample) from the wave and change its amplitude. In this mode, you always stay on the selected bar.

Draw

In this mode, you can also change the gain, but when you move horizontally, the controller switches to another bar.

Over

You overwrite bars on the selected wave. This can be recorded into a new wavetable, using **Record** mode in the wavegrid.

Parameter Page

The parameter panel

The parameter panel is divided into functional groups of controls. Each group has a context menu, which is marked by the little triangle in the top right corner. There you find well known commands like copy/paste and also a help command. There are different kinds of controls, which will be described below.

Value Controls:

These controls set the value of one synthesizer parameter. They normally range from 0 to 1. However there are parameters, which have a plus/minus range. So the zero value is in the center. All controls can be reset to their default value, by touching the control and then doing a second tap somewhere on the panel.

To fine adjust a value, move your finger away from the starting point to the right. The same works for coarse adjustment to the left. If you are left-handed, you may change the setting on the **Setup** page.

Value controls with routing:

These controls function like the value controls, but have an additional routing selector. If you double-tap on it, a popover list appears, where you can activate the routing.



Oscillators

Wave Generator has 3 audio oscillators, which can be very flexibly controlled and routed. Each oscillator may use its own envelope to control the wave access, and its own LFO to control the pitch. The oscillators have four modes of operation. **Audio 1** is the standard audio mode which has the most possible overtones. However in some cases it may be more useful to use the **Audio 2** mode, which has a softer sound. Especially for high pitches it may be better to use mode 2. There is also a sub-audio mode, which sets the pitch below audio range, so it can be used as an adaptable waveform LFO. Finally there is an **off** mode, which simply saves processor power.

The pitch section:

Here you find the standard parameters like **Octave** and **Semitones**. The **Keyboard** tracking para is used to setup precise tracking of the oscillators. In this way very fine detunings spread across the keyboard are possible.

Modulat 1 has noise and frequency modulation. Double tap on the control to open a popup list and select from a list of modulation sources. **Modulat 2** works in the same way.

Please note, that the **Glide** only works in **Legato** keyboard mode.

The wave section:

Here you will find various options for controlling wave access of the 3 oscillators. The **W Offset** para shifts the path you have setup inside the wave-grid. If you tap the **Para** page selector a second time, you see the wave-grid together with the oscillator and envelopes. This way it is easy to see, how the wave controls affect the actual path in the grid. The display changes with the oscillator selected.

The Blending parameter works as a smoothing function as the oscillator progresses through the waves. When set to 1, it gives you hard switching, 0 gives the smoothest blend.

The Horizontal switch, also controls the wave offset. To demonstrate this, select preset "3 Point", and switch the para page to half-mode, so that you can watch the green light point. The point moves on the path. Now set the W Offset to -1. you see, that the played path now is offset 1 wave. If you set -2 the offset increases. At -16 the offset is a full grid column, so the path is now parallel shifted to the left. Now if you activate the Horizontal switch, the path is only allowed to offset in horizontal direction. If you change the Offset, you can verify this. Each time the offset is another 16 steps away, the light point moves more sideways.

Of course the most important controller for the waveform, is the envelope. Here you have three envelopes, which can be assigned to the oscillators. If you select Own this oscillator uses its own envelope. For oscillators 2 and 3, you also can select the envelope from oscillator one. If you tap on the control, the envelope display switches to the corresponding envelope, so you have immediate access to it. If you set the routing to off then a constant value is used which can be adjusted by the value of the envelope parameter.

Envelopes

In WaveGenerator you may use up to 13 independent Envelopes. In the popover list you find short descriptions on how each envelope is used as default. However a single envelope can also be used by other modules. E.g. you can also use envelope W 1 for the wave control of oscillator 2 and 3.

The envelope types:

The envelopes can be configured as normal ADSR type envelopes, or as a endless looping type. In the loop mode, the envelope goes into decay and then rises again to a second peak level, where it decays again and so on. However not all envelopes have this feature. e.g. the gain envelope must always decay to zero after some time, so it doesn't have the loop mode. For the wave controls a loop can be very useful, as it creates a lively sustain sound, like a sampler does when it loops. You can activate the loop via the context menu, in the envelope module.

The control points:

The envelope has 3 to 5 control points, dependant on its mode. If you select the gain envelope **G1** you see only the normal three control points needed for an ADSR envelope. With the peak you control the Attack time, with the second point, the Sustain as well as the decay time, with the third point the release time. Nothing special here.

If you look at a wave controller envelope, like **W1**, you have 4 points, if it has no loop. Additional to the normal ADSR you have a point at time zero. This point shifts the base level of the envelope up and down. Which is very important for the wave control, because you don't have an extra base parameter there. You may even move this point higher than the peak ! Which then inverts the envelope.

Also the 4th point behaves different, as in ADSR. You may move this point up and down also, but it acts somewhat different than the zero point.

Now if you are in loop mode, you have 5 points. The 4th point controls the width of the loop, and the 5th point offers a random component to the loop. If you move point 5 up, the random effect increases, move it down and you get more regular periods. Just try it out.

Besides all this, there are control points between the main points, which let you **bend** the envelope curves.

If two or more control-points come too close to each other, there is another way to select the point you want to use. Therefore double-tap near the points, and leave the finger on the screen on the second tap. Now move the point as desired. The active point is always highlighted.

The envelope time scale automatically changes according to the release endpoint. The end time of the scale is shown in the little **TIME** field in the top right corner. Each envelope has its own velocity attenuator, which you may adjust in the top right corner of the envelope display. The velocity is controlled either by external MIDI keyboard, or by the vertical position where you tap the key.

Filter

The filter module is used to filter spectral parts of the oscillator and noise signals. The audio input of the filter is fed by a mixer. This mixer is not displayed in an extra module, its inputs are controlled by the gain faders in the oscillators and the noise module. Note, that **Noise 1** is the audio noise source, while **Noise 2** and **3** are only used for modulation purposes.

The base section:

Here you find the main filter parameters, like **Cutoff** frequency and **Emphasis**.

The filter can operate in one of three modes:

Normal This is the well known 24dB lowpass.

Drive In this mode the filter is overdriven and goes into saturation.

Bypass The filter is not used and the mixer signal is routed directly to the output side of the filter.

The modulation section:

Here you find the **Keyboard** tracking para and two Modulation inserts. These work similar to the other routing selectors in the other modules. Double tap opens the selection popover box, and offers various modulation sources. Note, that the selected source is always attenuated by the value inside the control. Here we have bipolar controls, meaning that the source signals may be inverted if you select negative values.

Dual Amplifier

The Dual Amplifier module controls two independent gain controls, also known as VCAs in analog systems.

The Audio section:

The **Audio 1 / 2** inputs select the audio sources for each VCA.

Note that the Osc1,2,3 signals are taken directly from the oscillator waveforms, they are not attenuated by the **Volume** faders inside the oscillator modules. The noise signal is always **Noise 1**, with its **Gain** and **Color** controls.

With the **Spread** you can separate the 2 outputs to the left and right channel.

The Control section:

VCA 1 is always controlled by envelope #1. For VCA 2 you may select another envelope. The panning may be dynamically controlled by parameter **Pan Mod**. The **Velocity** control sets the velocity gain for both VCAs.

LFO

WaveGenerator comes with 4 LFO's, which may be selected in the header bar of the module. If you tap on a routing controller inside another module, which uses a LFO as modulation source, the corresponding LFO will also be selected.

Each LFO may be controlled by an envelope, another LFO or the CX, CY and velocity controllers. You select the modulation source by double tapping the **Intensity** control.

The **Shape** has a special feature besides the standard waveforms, in that you may vary the ON/OFF ratio of the waveforms. Something which is common for rectangular waves, is also applicable here for the sawtooth and sine waveforms.

The **Speed** parameter may be synced from an external MIDI clock.

The **Offset** selector makes it possible either to have the LFO wave centered around zero, or to have it only above zero, or below.

Arpeggiator

The Arpeggiator module (abbrev. *Arptor*) is a combination of a small step sequencer and arpeggiated playback.

You may record up to 16 notes, then switch to **Play** and select the appropriate play mode.

The **Range** parameter defines the overall length of the arpeggio. If you record 3 notes, and set the **Range** to 8 and use **UP** mode, the sequence of notes will be: 1,2,3,1,2,3,1,2, now repeat 1,2,3...

The mode can be changed by double tapping on the **Range** control and selecting it from the popup menu.

For info on synchronisation, please look on the **Setup page** help.

Delay

WaveGenerator comes with a simple delay effect. The delay times control the overall duration of the effect. **Taps 1** controls the delay time of the reverb part, while **Taps 2** the pre-delay part.

With **Mix** you setup the reverb part of the sound compared to the original signal.

Also in this section you find the **Master** Volume control for the whole program.

3D Page

Image Transformer

Image Transformer can transform an image into a wavetable. You may select a photo from your album or even take a pic with the camera.

There are two ways the transformer works:

Wave:

In wave mode, the image is taken row by row, and directly copied into the wavetable.

Spectrum:

In spectrum mode, the rows of the image are interpreted as spectra, and then transformed into waves. So the 3D always shows the resulting waveforms.

The transformer always occupies the left half of the wavegrid.

The previously loaded content is erased.

To display the first 128 waves of your wavetable (independent of the path, and synth settings) use "Display All".

Setup Page

Setup

This page lets you setup your basic system parameters, like sample rate and MIDI input. You should enter your personal signature, which will be shown in the sound programs you create.

There is also a little MIDI monitor built in, which shows the incoming CC and MIDI clock. If you use MIDI via the Network, ensure that the iPad is connected (settings -> bluetooth), not forgetting your host as well.

Number of voices

The maximum number of voices you can play is limited by the system power. It is lower in an iPad 1 than in the second and third generation devices. If you setup the highest quality, which is 44100 Hz, and set the number of voices too high, then you may get dropouts in the audio signal. If that happens, then you will have to reduce either the sample rate or the number of voices.

Audio Mix mode

This is important, if you want to combine WaveGenerator with other synth, or sequencer apps.

If **Mix** is set to **off**, then WG is the only app that may generate audio. This means if you close WG and open another audio app, WG will stop playing and cannot receive MIDI anymore.

If **Mix** is set to **on**, then the audio is mixed with other apps. Now you can control WG from sequencers or other synths which feature MIDI out.

MIDI input

WaveGenerator has two MIDI inputs. One is exposed to other apps, the other is active only if you select a MIDI source with the MIDI selector.

It depends on the other app you use, which method is best and possible. Some seq. apps show a list of MIDI inputs, and you can select which one should play the sequence. Other apps just expose their MIDI out, and you must select that one in WG's MIDI selector.

MIDI receive channel

If this parameter is set to zero, WaveGenerator operates in Omni mode, otherwise in Poly mode with the selected channel.

MIDI Mod-wheel is routed to the CY control, and channel aftertouch to CX.

Synchronisation

The Arptor and the LFOs may be synced to external MIDI. You can verify that the external signals are received by your iPad, using the little

MIDI monitor display on the setup page. When the BPM display shows the correct value, you may activate the sync with the **Arptor sync** and **LFO's sync** buttons. In this case the speed parameters act as ratio for the clock speed. So if the external sequencer is running on 120 BPM and you set the Arptor speed to 120 or 130 the arpeggio runs on the same speed as the sequencer bars. If you turn up the speed, lets say to 200, the Arptor will sync into double rate.

CC display

You may check incoming MIDI control values in the CC display. On the **Para** page, only the most important paras are tracking the values. Please note, that most CC's will change the current program parameters.

Main Controllers

CC#	DESTINATION
001	CY controller
002	CX controller
003	-
004	-
005	-
006	-
007	Master Volume
008	-
009	-
010	-

Oscillator 1 Parameters

CC# DESTINATION

020 Glide

021 Pitch Mod 1

022 Pitch Mod 2

023 Envelope intensity

024 Wave Mod 1

025 Wave Mod 2

026 Wave Offset

027 Wave Blending

028 Volume

Oscillator 2 Parameters

CC# DESTINATION

030 Glide

031 Pitch Mod 1

032 Pitch Mod 2

033 Envelope intensity

034 Wave Mod 1

035 Wave Mod 2

036 Wave Offset

037 Wave Blending

038 Volume

Oscillator 3 Parameters

CC# DESTINATION

040 Glide

041 Pitch Mod 1

042 Pitch Mod 2

043 Envelope intensity

044 Wave Mod 1

045 Wave Mod 2

046 Wave Offset

047 Wave Blending

048 Volume

Noise 1 (audio) Parameters

CC#	DESTINATION
050	Gain
051	Color

Filter Parameters

CC#	DESTINATION
055	Cutoff
056	Emphasis
057	Modulation 1
058	Modulation 2

Pedals

CC#	DESTINATION
060	Sustain Pedal
061	reserved
062	reserved
063	reserved

LFO 1 Parameters

CC#	DESTINATION
070	Intensity
071	Shape
072	Speed

LFO 2 Parameters

CC#	DESTINATION
073	Intensity
074	Shape
075	Speed

LFO 3 Parameters

CC#	DESTINATION
-----	-------------

076	Intensity
-----	-----------

077	Shape
-----	-------

078	Speed
-----	-------

LFO 4 Parameters

CC#	DESTINATION
-----	-------------

079	Intensity
-----	-----------

080	Shape
-----	-------

081	Speed
-----	-------

Envelope 1 (wave osc 1)

CC#	DESTINATION
-----	-------------

090	A
-----	---

091	D
-----	---

092	S
-----	---

093	R
-----	---

094	Base
-----	------

095	Peak
-----	------

Envelope 2 (Gain Ampl. 1)

CC#	DESTINATION
-----	-------------

096	A
-----	---

097	D
-----	---

098	S
-----	---

099	R
-----	---

Envelope 3 (filter)

CC#	DESTINATION
100	A
101	D
102	S
103	R
104	Base
105	Peak

Envelope 4 (wave osc 2)

CC#	DESTINATION
106	A
107	D
108	S
109	R
110	Base
111	Peak

Envelope 5 (wave osc 3)

CC#	DESTINATION
112	A
113	D
114	S
115	R
116	Base
117	Peak

Envelope 6 (noise 1)

CC#	DESTINATION
118	A
119	D
120	S
121	R

Dual Amplifiers

CC#	DESTINATION
-----	-------------

122	Audio 1 gain
-----	--------------

123	Audio 2 gain
-----	--------------

124	Spread
-----	--------

125	Gain Mod
-----	----------

126	Panning Mod
-----	-------------

127	VCA 2 envelope gain
-----	---------------------

Browser Page

Browser

The browser page offers a number of easy ways to manage your program and sound banks. This includes the copying and sorting of individual programs into other, or new program banks.

The page is divided into three parts: The Program browser, the Program manager and the Bank manager.

The Program Browser

The order of the programs inside the browser is controlled by the mode selector, left above the browser. This mode acts like a filter. The default setting is **All** this means that all categories are displayed at once. In this case the programs are grouped into categories. Each one has a grey bar above the list of programs. On the right side there is an extra vertical scale, which shows all the available categories. If you tap on one, the browser scrolls to the beginning of that category.

When you select a category as filter, the browser only displays programs from that category. If you set the filter to **Unsorted**, then the list shows all programs as they are ordered in the bank, which is the order you get when you step through the programs.

You may change the category in which your program appears, inside the browser itself. Therefore the selector must be set to **Unsorted** and the first property selector must be set to **Category**. Now you simply tap inside the browser line of the desired program, and shift sideways. If you copy a program, with **Copy** and **Paste New**, the new program has the old category.

Right above the browser, there are column filters, which you can use, to display certain information about the programs, like create date, or keyboard info.

The Program Manager

The top left field contains tools to manage the programs inside the active bank. You may select the active bank, with the popup list.

The **Delete** button, deletes the active program. **Copy** makes a copy and puts it inside the destination bank. That is the bank, you have selected in the **Bank Manager**. The text input field allows you to write a comment for your bank.

The Bank Manager

Here you administer your bank files. Each bank contains up to 100 programs. To create a new bank, tap **New**. Then you have an empty bank as destination. Now you may copy programs from your current bank into the new one.

Delete removes the selected target bank from the file system.

Save As makes a copy with a new name.

<https://www.facebook.com/PPGWaveGenerator>
<http://wolfgangpalm.com>